



The Pro-Installer's Guide to a Perfect Windscreen Fit

Top Tips & Tricks from Midwest Cover

Professional installation ensures durability and aesthetics.

Follow these steps for a wrinkle-free finish.



Part 1: Pro-Prep (Before You Unroll)

- **Check the Weather:** Never install on a windy day; wind turns the screen into a sail.
- **Use Your Diagram:** Match labeled panels to your fence sections before starting.
- **Find the “Front”:** Install with the smooth, finished side facing the field.
- **Find the “Top”:** Air vents (half-moon cutouts) always go at the top.



Part 2: The 10-Foot Section Method

- 1. Start at Top Corner:** Secure to fence mesh, not the rail.
- 2. Hang the Top:** Zip tie every grommet for 10 feet. Pull taut, don't stretch.
- 3. Attach Side:** Go back and secure the vertical edge.
- 4. Attach Bottom:** Secure the bottom for that 10-foot section.
- 5. Repeat:** Move to the next 10 feet.



Part 3: The "Don'ts" — Avoid These Mistakes!

- **Mistake: Skipping Grommets. Solution:** Zip tie EVERY grommet to prevent tear-out.
- **Mistake: Wrong Hardware. Solution:** Use 50 lb. UV-resistant zip ties that won't break in extreme weather.
- **Mistake: No Bottom Gap. Solution:** Leave 6-12 inches at the bottom for airflow and mower clearance.